

The Wave Setup Instructions



**BALLANCE
DISPLAY**

A Division of Ballance Design Ltd.

Component list for your Wave Display

- 1 Frame (# of pieces depending on model)
- 2 Weighted Feet
- 1 Fabric Graphic Sleeve
- 1 Portable Carrying Bag



1. Open your Wave display case and remove all the pieces of your display.

2. Proceed to connect all numbered frame pieces with their corresponding parts as shown in the image to the left. ie. #8 connects to #8 etc.

3. Once you have connected your frame together slide the Fabric Graphic over the top of the frame and spread it across the frame.

4. Zip up the graphic along the bottom of the frame.



If you have any further questions call

1-888-774-4403

www.ballancedisplay.com